


# The MIRI medium resolution spectrometer for the James Webb Space Telescope

David Lee (UKATC)

On behalf of the MIRI spectrometer team

SPIE 6265-38, 26 May 2006







# MIRI System Overview




## MIRI has four functions:

- Mid-Infrared Imaging from 5 to  $27\mu\text{m}$ ,  $0.11''$  pixels,  $1.3' \times 1.7'$  field of view
- Coronagraphic Imaging (at 10.65, 11.4, 15.5,  $23\mu\text{m}$ )
- Low Resolution Slit Spectroscopy  $R \sim 100$  from 5 to  $10\mu\text{m}$
- Medium Resolution Integral Field Spectroscopy,  $R \sim 3000$ , from 5 to  $28.3\mu\text{m}$






# MIRI Optical Module – Key Design Features



- Lightweighted, all aluminium, modular optical system
- Supported by thermally isolating carbon fibre hexapod which attaches to ISIM structure.
- Cooled to  $\sim 7\text{K}$  by a dedicated cryo-cooler
- Three  $1\text{k} \times 1\text{k}$  SiAs detectors.
- 4 Mechanisms – 3 wheels based on ISO design (filters, dichroics, gratings) and a contamination control cover
- Light enters from the telescope via the pick-off mirror
- The fields of view of the Imager and the Medium Resolution Integral Field Spectrometer are defined and separated in an “Input optics/calibration module”
- Imager optics on one side of primary structure, spectrometer on the other






## MIRI spectrometer scientific requirements





- **Wavelength range 5 – 28 microns**
- **Field of view not less than 3.5 x 3.5 arc-seconds squared**
- **Spatial sampling to match FWHM of JWST PSF**
- **Spectral resolving power**
  - $5_{\mu\text{m}} < \lambda < 10_{\mu\text{m}} \text{ } R > 2400$
  - $10_{\mu\text{m}} < \lambda < 15_{\mu\text{m}} \text{ } R > 1600$
  - $15_{\mu\text{m}} < \lambda < 28_{\mu\text{m}} \text{ } R > 800$
- **Image quality: 80% EED @  $8_{\mu\text{m}}$  < 1.1 x 80% EED of an unaberrated JWST – translated to an RMS wavefront error specification for the sub-systems**
- **Detector format: Two 1024 x 1024 SiAs arrays with  $25_{\mu\text{m}}$  pixels**





# Optical path through MIRI spectrometer











## SPO – layout of dichroic level




## SPO – dichroic wheel assembly EQM




CdTe filter


Diamond machined  
aluminium wheel






## SPO – verification model chassis hardware











## APO verification model hardware







## SPO – Integral Field Unit




For more details on the mirror arrays, manufactured at Cranfield University, see talk 6273-74, Mon 14:00








## IFU assembly




**Assembly carried out in class 100 clean room**









# SMO – opto-mechanical layout







# SMO – optical layout of camera optics


---





## SMO – grating wheel mechanical hardware






## SMO – mechanical structure





Short wavelength  
spectrometer  
(Channel 1 + 2)






Grating assembly

Long wavelength  
spectrometer  
(Channel 3 + 4)





## SMO – qualification model assembly




### QM is



- Manufactured
- Assembled
- Verified regarding alignment
- Vibration tested
- Verified regarding alignment










## SMO – QM Alignment inspection






**Vibration Test**



## Modelled performance for channel 2 at 8 $\mu\text{m}$




Full end to end optical system analysis done using physical optics propagation tool in zemax



Specsim - MIRI spectrometer simulator described in Lorente et al. 6274-55





## Summary and status

---



- **Opto-mechanical design complete. Both SPO and SMO have completed CDR**
- **Verification model hardware**
  - SPO components have been received
  - SMO CMs are ready
  - SMO M1-1, M1-2 and M3 are ready to be gold-coated
  - SMO VM Gratings on track for a June 2006 delivery
- **Most of sub-system testing now complete**
- **Assembly of Verification Model in progress**
- **Delivery of spectrometer sub-systems to Rutherford Appleton Laboratory for integration and test into MIRI VM will be later this year**




**MIRI draws on the expertise of the following organizations:**

**Ames Research Center, USA; Astron, Netherlands Foundation for Research in Astronomy; CEA Service d'Astrophysique, Saclay, France; Centre Spatial de Liège, Belgium; Consejo Superior de Investigaciones Científicas, Spain; Danish Space Research Institute; Dublin Institute for Advanced Studies, Ireland; EADS Astrium, Ltd.U.K, European Space Agency, Netherlands; Institute d'Astrophysique Spatiale, France; Instituto Nacional de Técnica Aeroespacial, Spain; Institute of Astronomy, Zurich, Switzerland; Jet Propulsion Laboratory, USA; Laboratoire d'Astrophysique de Marseille (LAM), France; Lockheed Advanced Technology Center, USA; Max-Planck-Institut für Astronomie (MPIA), Heidelberg, Germany; Observatoire de Paris, France; Observatory of Geneva, Switzerland; Paul Scherrer Institut, Switzerland; Physikalisches Institut, Bern, Switzerland; Raytheon Vision Systems, USA; Rutherford Appleton Laboratory (RAL), UK; Space Telescope Science Institute, USA; Toegepast-Natuurwetenschappelijk Onderzoek (TNO-TPD), Netherlands; U.K. Astronomy Technology Centre (UK-ATC); University College, London, UK; Univ. of Amsterdam, Netherlands; Univ. of Arizona, USA; Univ. of Cardiff, UK; Univ. of Cologne, Germany; Univ. of Groningen, Netherlands; Univ. of Leicester, UK; Univ. of Leiden, Netherlands; Univ. of Leuven, Belgium; Univ. of Stockholm, Sweden, Utah State Univ. USA**







## SPO – VM dichroic wheel assemblies

---

